

FIG. 1A

51




FIG. 1B

A perspective view of a handheld electronic device 100a. The device is shown with its cover 175 open. The main display 105 is visible, along with a sub-display 106a and a control panel 75. The control panel includes several buttons, some of which are labeled 106b. A hinge 80 is visible on the right side of the device.

FIG. 2

1802




Fig 3



09728023-13000




FIGURE 5


[illegible]

FIGURE 6

100




FIG. 7





OFFICE OF THE COMPTROLLER

100




FIGURE 8




Figure 9




FIGURE 10




FIGURE 11



OFFICE

100

200

700

600

201

SEPT						
S	M	T	W	Th	F	S
					1	2
3	4	5	6	7	8	9
10	11	12	13	14	15	16
17	18	19	20	21	22	23
24	25	26	27	28	29	30

OCT						
S	M	T	W	Th	F	S
1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31				

NOV						
S	M	T	W	Th	F	S
5			1	2	3	4
6	7	8		9	10	11
12	13	14	15	16	17	18
19	20	21	22	23	24	25
26	27	28	29	30		

000000

FIGURE 12

100




FIG. 13





FIGURE 14.



500

FIGURE 15







Figure 16

500

**1700**



**Figure 17**




Figure 18